



SPORTSTAR 241BM

No VOR OPERATION. Use GPS →

DYNON
EFIS-D100

GARMIN
SL40



FMS JOYSTICK

Cancelling a direct-to:

- 1) Press the Direct-to Key to display the Direct-to Window.
- 2) Move the FMS Joystick to highlight 'Stop Navigation'.
- 3) Press the ENT Key.

Cancelling a Flight Plan:

- 1) Press the FPL Key.
- 2) Press the Menu Key.
- 3) Turn or move the FMS Joystick to highlight 'Stop Navigation' or 'Resume Flight Plan' if a flight plan was active.
- 4) Press the ENT Key. If a flight plan is still active, the system resumes navigating the flight plan.

SPORTSTAR 125MX VOR OPERATION


DYNON
EFIS-D100

GARMIN
SL30



Buttons one and six cycle to the previous and next screens, respectively

Use outer D100 buttons to bring up split screen
If required use menu to find "NAV SRC" to show VOR




Push "NAV" to enter nav aid frequency
Flip/Flop into active frequency
Push "OBS" Select
Turn inner knob to set VOR radial
(Switch back to "COM" for normal opp)

Cancelling a direct-to:

- 1) Press the Direct-to Key to display the Direct-to Window.
- 2) Move the FMS Joystick to highlight 'Stop Navigation'.
- 3) Press the ENT Key.

Cancelling a Flight Plan:

- 1) Press the FPL Key.
- 2) Press the Menu Key.
- 3) Turn or move the FMS Joystick to highlight 'Stop Navigation' or 'Resume Flight Plan' if a flight plan was active.
- 4) Press the ENT Key. If a flight plan is still active, the system resumes navigating the flight plan.



FMS JOYSTICK

SPORTSTAR 907SL VOR OPERATION



Garmin GNS 430

Enter VOR frequency

ID VOR

Set "CDI" to read VLOC

Twist "OBS" on VOR analog instrument to set radial

Garmin 430 Direct-To (→):

Direct-To navigation can be canceled by pressing the Direct-To key followed by the MENU key.

With the command "Cancel Direct-To Nav?" displayed, press the ENT key to specify "yes".

All references to a destination (and a magenta course line) will then disappear.

HARMONY 797ST VOR OPERATION



Garmin G3X

Garmin GTN 750
touch screen

Garmin GTN 750:

Go to MAP page
Set "CDI" to "VLOC"
Enter "STBY" VOR/NAV freq
Push "NAV" to flip/flop active freq

Garmin G3X:

Push VOR CRS button
Spin knob to desired radial

